

# FX1200e Setup Instructions

**Tools Required:** #2 Phillips Screwdriver or Drill Driver, Scissors

1. Open crate on the ramp side by removing the 8 Phillips screws marked with red dots. Start removing screws from the bottom first and then work your way to the top. Hold the ramp when removing the last screws to prevent the door/ramp from falling forward.
2. Once the screws are removed the door will open from the top with a hinge at the bottom. The door will act as a ramp to remove the FX1200e.
3. Remove two foam padded shipping braces.
4. Unlock the two accessible casters on the FX1200e by pushing upward on the lock mechanisms.
5. Pull FX1200e out of the crate. Make sure you have at least 3.6 meters (12 feet) of clearance from the end of the crate before pulling the FX1200e out of the crate.
6. Use a scissors to remove the shrink wrap. Remove tape from the supply and take up rollers, the cutter cover and cabinet doors.
7. Open the front cabinet doors and remove boxes from cabinet. Please note there is a latch on the bottom of the left door.
8. The following items are contained in each box:

## **Supply Box**

- 10 Slitter Blades
- 10 Knife Holders w/ Knives
- Power Cord
- Registration and Warranty
- 10 Plastic Depth Gauges
- 2mm & 3mm Hex Drivers
- Utility Knife

## **Touch Screen Computer Box**

- Touch Screen Computer
- 4 Silver Mounting Screws
- Power Cord/Power Supply

## **Media Box**

- Sample Roll
- Laminate Film Sample
- Cardboard Cores

**Note:** The Operator's Guide is located in a plastic sleeve mounted inside the cabinet door.

9. Attach the touch screen to the mounting bracket using all four silver mounting screws found in the touch screen computer box. This procedure is easier with two people.

--OVER--

511244-100610

10. Connect the touch screen power supply to the power port located on the bottom left side of the touch screen. Route the cable away from the cutter using the cable clip attached to the bottom of the touch screen mount. Plug the power cord into a surge protected power strip.

**Do NOT turn on the touch screen computer yet!**

11. Connect the USB cable to the USB port on the right side of the touch screen. The USB cable will be taped to the right side of the FX1200e.
12. Attach the ground strap to the top left screw located on the back of the touch screen computer mounting bracket.
13. Remove the power cord, slitter blades (yellow plastic container), cutter knives with holders and hex drivers from the supply box.
14. Plug in the power cord on the back right side of the FX1200e. Turn on the power switch. Plug the power cord into a surge protected power strip.

Note: The cutter initializes when the power is turned on so the sound of cutter carriage movement should be heard.

15. Turn on the monitor by pressing the power button on the top left side. The computer will boot up and the PTFinish Software will automatically start.
16. Open the media box. Remove the sample roll, laminate and cores. Watch the video tutorial (on the touch screen) to cut the sample roll.

**Congratulations! You have setup your FX1200e.**

**For operating instructions consult the Operator's Guide located in a plastic sleeve mounted inside the cabinet door.**